


# Using Group2call with Weather Message


The following instructions describe the setup for sending weather voice alerts using Group2call's Voice Message Broadcast service.

1. Sign up for a new Group2call account at [www.group2call.com](http://www.group2call.com)
2. Log into Group2Call and click Account Settings. Under Account Settings, click Contact Information. Enter your email address in the Email2Voice Access field. This is the From Email address setup in Weather Message. Save this change.
3. Click Contacts and add the contact names and phone numbers for the people who will receive the alerts.
4. Click Groups and create a new group that will receive alerts and add contacts to this group. You can enter multiple groups. In the following example the group is named EMA:



The screenshot shows the 'Groups' management interface. At the top, there are two input fields: '\* Group Name' with the value 'EMA' and 'Group Description' with the value 'EMA Personnel'. To the right of these fields is a button labeled 'Group Options'. Below the input fields, there are two main sections: 'Available Contacts' on the left and 'Selected Contacts' on the right. The 'Available Contacts' section contains a list of contacts with checkboxes: 'My Groups' (checked), 'My Contacts' (checked), 'Lloyd, Danny' (unchecked), and 'Lloyd, Danny Cell' (unchecked). Between the two sections are two buttons: 'Add ->' and '<- Remove'. The 'Selected Contacts' section contains a list of contacts: 'Lloyd, Danny' and 'Lloyd, Danny Cell'.

5. Open Weather Message Setup and click Support Setup menu, then Email Groups.



6. Create a new email group. One email group will need to be setup for each group setup in Group2Call. Here is an example for the Group2Call EMA group.

The E-Mail list box must contain the name of your Group2Call group followed by @group2call.com.

The Subject Override field allows you to send commands to the Group2Call server. The following variables are supported:

\$adssupport\$	This code allows you to send free text to voice messages.
\$kate\$	Use the Kate voice.
\$daniel\$	Use the Daniel voice.
\$paul\$	Use the Paul voice.

Now click the Create Group E-Mail Header / Trailer.

Enter ## in the Header field and \$\$ in the Trailer field. These codes are required for Group2Call to process the email properly.

Click Save to accept the Header / Trailer. Click Save again to save this group.

Repeat these steps to setup additional groups.

- Now setup an alarm to use this new group. The following example sets up an alarm to send all warnings to our new EMA group.

**New Alarm - WRN???**

List Products   List Forecast Offices   List States

Alarm   Client/ Map/ X10   Paging/Email/Fax   Archive/Html/Exe/Print

Product: WRN???   Tornado, Thunderstorm, Flash Flood Warning, etc  
All Offices

States: ☒ Alabama, ☐ Alaska, ☐ West Atlantic Ocean, ☐ Northwest Atlantic, ☐ Arkansas

Counties: ☐ Sumter (ALC119), ☐ Talladega (ALC121), ☒ Tallapoosa (ALC123), ☐ Tuscaloosa (ALC125), ☐ Walker (ALC127), ☐ Washington (ALC129)

Match Text:    RegEx: ☐  
Exclude Text:    RegEx: ☐   Alarm Active: ☒

Buttons: Save, Cancel

Click the Paging/Email/Fax tab and select the EMA Email Group.

**New Alarm - WRN???**

List Products   List Forecast Offices   List States

Alarm   Client/ Map/ X10   Paging/Email/Fax   Archive/Html/Exe/Print

E Mail: ☒ EMA, ☐ None, ☐ Danny, ☐ DannyShort

Fax Group: ☐ None, ☐ FaxOffice

Pager: ☐ None, ☐ DannyTap, ☐ David, ☐ Group1

Time Restrict: No

Time Begin:  HH:MM - Start Receiving  
Time End:  HH:MM - Stop Receiving

Days of Week: S M T W T F S (all checked)

Buttons: Save, Cancel

Click Save to accept this new alarm.

This completes the steps necessary to setup and email group and alarm to send voice alerts using the Group2Call system.